

Replacement Sideskirt Decal Fitting Guide

1. Remove old decal

You may want to carefully use a hair dryer/heat gun on a LOW heat to help soften the glue to aid removal.



2. Thoroughly clean & prepare surface

Pre-wash the area using either soap and water or a mixture of rubbing alcohol (70% isopropyl alcohol) and water. Rinse thoroughly with water until no soap or residue remains. Do not use window-cleaning or quick detailing products as they may leave a residue behind, making your sticker cling less effectively.



3. Lightly spray bodywork with a very light mist of water (optional)

Using a 'wet' application method can help avoid small air bubbles and gives a limited amount of ability to move and reposition the sticker for a few seconds before it grabs. This will make positioning easier. Use a mist spray of water only. Too much water will mean the sticker takes a much longer time to adhere before you can remove the clear transfer paper, or may fail to stick completely.



4. Peel off backing to half way point of sticker and fold back on itself

With the sticker face down, peel the paper backing layer back on itself, making sure the sticker remains stuck on the clear application tape. If any part of the sticker stays stuck to the paper backing, place back down, rub over with a plastic card and try again.

5. Apply first half of sticker to sideskirt using guideline for positioning



6. Peel off remaining backing, and apply remaining half of sticker



7. Gently rub over decal with a plastic card to help adhesion and remove any bubbles



8. If the wet application method was used (step 3), allow 10 minutes for water to dry and adhesive to adhere. Repeat rubbing over the decal with a plastic card during this time to push out water from under the sticker.

9. Remove the clear application tape

Gently start to peel off the clear application tape from one end, making sure to stop and repeat step 7 if any part of the sticker lifts.

The positioning guideline can be removed at this stage, or if it has stuck it can be peeled off at the end.



10. Leave sticker for at least 48 hours before wiping or washing over it, and always avoid directly pressure washing over the area in future to extend its life.

